


# Nikon


# Canon

## UNLEASHED N1




D200 *	D2Hs *
D300 *	D2X *
D300s *	D2Xs *
D500	D3 *
	D3X *
D700 *	D3s *
D800 / D800E	D4
D810 / D810A	D4s
	D5

## UNLEASHED C1




5DSR  
5D Mark IV  
1DX Mark II

## UNLEASHED N2



D600 \*  
D610  
D750  
Df  
  
D5200\*

## UNLEASHED C2




1100D / T3 \*  
1200D / T5  
1300D / T6

100D / SL1

500D / T1i \*  
550D / T2i \*  
600D / T3i \*  
650D / T4i  
700D / T5i  
750D / T6i  
760D / T6s

## UNLEASHED N3



D3100 *	D90 *
D3200 *	D7000 *
D5000 *	D7100
D5100 *	D7200
D5200 *	
D5300 *	
D5500 *	

60D / 60Da \*  
80D

7D  
6D

5D Mark II \*  
5D Mark III

\* a short, flexible cable with small right-angle plugs is necessary for most functions but not for remote triggering, intervalometer and geotagging.

For all other Nikons, the cable is only necessary for thumbnail preview!

\* Geotagging not available on these cameras

Unless there is very high demand, we currently do not plan to make a version for:

- av7D Mark II (it has a unique plug layout),
- for the 70D, 1DX, and 1DC and definitely not
- for Canons that came out before 2009.